

HOME OF THE
SILVER
weld through
HIGH QUALITY SHEETMETAL




Distribuito in Italia da:

CARS
CANTONE
accessori e ricambi

VOLKSWAGEN

T1 type 2 split window
Pick up

Type 2 Split Window



A 0890-149 / 211 703 599 03/55-07/67
CAB SEAT BOX

B 0890-152 08/62-07/67
SEAT RAILS AND SEAT BRACKETS

D 0890-134-0 / 211 801 051 03/55-07/58
FRONT FLOOR PAN COMPLETE LHD




F 0890-135-0 / 211 801 051H 08/58-07/67
FRONT FLOOR PAN COMPLETE LHD

C COMING SOON

E 0890-134-1 / 214 801 051B 03/55-07/58
FRONT FLOOR PAN COMPLETE RHD

G 0890-135-1 / 214 801 051E 08/58-07/67
FRONT FLOOR PAN COMPLETE RHD

Type 2 Split Window



A 0890-745 / 211 801 403E 03/50-07/67
FLOOR PLATE LEFT, NON CARGODOOR

C 0890-744 / 214 801 403M 03/50-07/67
FLOOR PLATE LEFT, CARGODOOR

E 0890-46 / 211 813 163 03/50-07/67
PLATFORM TRAY LEFT REAR

G 0890-48 / 211 813 167 03/50-07/67
COVER PLATE ENGINE LEFT


B 0890-755 / 211 801 404K 03/50-07/67
FLOOR PLATE RIGHT, CARGODOOR

D 0890-754 / 214 801 404E 03/50-07/67
FLOOR PLATE RIGHT, NON CARGODOOR

F 0890-47 / 211 813 164 03/50-07/67
BATTERY TRAY

H 0890-49 / 211 813 168 03/50-07/67
COVER PLATE ENGINE RIGHT

Type 2 Split Window




A 0890-595 03/55-12/59
SUPPORT FRAME UNDER RIBBED FLOOR

B 0890-596 01/60-07/67
SUPPORT FRAME UNDER RIBBED FLOOR

WHEEL HOUSES

T 1

Type 2 Split Window



A 0890-145 / 214 801 325A 03/55-07/67
WHEEL HOUSING FRONT LEFT

B 0890-155 / 211 801 326E 03/55-07/67
WHEEL HOUSING FRONT RIGHT


C 0890-328 / 211 801 561B 03/55-07/62
WHEELHOUSE REAR LEFT

D 0890-338 / 211 801 562B 03/55-07/62
WHEELHOUSE REAR RIGHT

E 0890-329 / 211 801 561C 08/62-07/67
WHEELHOUSE REAR LEFT

F 0890-339 / 211 801 562C 08/62-07/67
WHEELHOUSE REAR RIGHT

Type 2 Split Window



A 0158-210 / 214 831 051A 03/55-12/60
DOOR LEFT

C 0890-283 / 211 841 081B 08/58-12/60
CARGO DOOR FRONT RIGHT / REAR LEFT

E 0890-284 / 211 841 081C 01/61-07/63
CARGO DOOR FRONT RIGHT / REAR LEFT

G 0890-294 / 211 841 091C 01/61-07/63
CARGO DOOR REAR RIGHT / FRONT LEFT


B 0159-210 / 214 831 052B 03/55-12/60
DOOR RIGHT

D 0890-293 / 211 841 091B 03/55-12/60
CARGO DOOR REAR RIGHT / FRONT LEFT

F 0890-285 / 211 841 081D 08/63-07/67
CARGO DOOR FRONT RIGHT / REAR LEFT

H 0890-295 / 211 841 091D 08/63-07/67
CARGO DOOR REAR RIGHT / FRONT LEFT

Type 2 Split Window



A 0156-700 / 211 831 401 + 405 03/50-07/67
DOOR HINGE UPPER LEFT

B 0156-710 / 211 831 402 + 405 03/50-07/67
DOOR HINGE UPPER RIGHT


C 0156-720 / 211 831 411 03/50-07/67
DOOR HINGE LOWER LEFT

D 0156-730 / 211 831 412 03/50-07/67
DOOR HINGE LOWER RIGHT

E 0156-820 / 211 841 511A 03/55-12/60
DOOR HINGE CARGO FRONT UPPER/REAR
LOWER (DOOR RIGHT)

F 0156-830 / 211 841 541A 03/55-12/60
DOOR HINGE CARGO FRONT LOWER/REAR
UPPER (DOOR RIGHT)

Type 2 Split Window




A 0157-600 / 211 829 105 03/55-07/63
TAILGATE

B 0157-601 / 211 829 105 03/55-07/63
TAILGATE DELUXE

C 0157-610 / 211 829 105Q 08/63-07/66
TAILGATE

D 0157-620 / 211 829 105Q 08/66-07/71
TAILGATE

Type 2 Split Window




- A** 0436-530 / 211 8471 605D + 211 841 661A+665A
CARGO DOOR LOCK MECHANISM WITH LOCKING RODS
RIGHT FRONT /LEFT REAR 03/55-07/62
- C** 0436-540 / 211 841 605D + 211 841 661B+665B
CARGO DOOR LOCK MECHANISM WITH LOCKING RODS
RIGHT FRONT /LEFT REAR 08/62-07/67
- E** 0436-420 / 211 837 015B 03/50-12/60
CAB DOOR LOCK MECHANISM SET LEFT
- G** 0436-430 / 211 837 016B 03/50-12/60
CAB DOOR LOCK MECHANISM SET RIGHT

- B** 0436-535 / 211 841 705A + 211 841 761A+765A
CARGO DOOR LOCK MECHANISM WITH LOCKING RODS
RIGHT REAR /LEFT FRONT 03/55-07/62
- D** 0436-540 / 211 841 605D + 211 841 661B+665B
CARGO DOOR LOCK MECHANISM WITH LOCKING RODS
RIGHT FRONT /LEFT REAR 08/62-07/67
- F** 0436-421 / 211 837 015C 12/60-12/63
CAB DOOR LOCK MECHANISM SET LEFT
- H** 0436-431 / 211 837 016C 12/60-12/63
CAB DOOR LOCK MECHANISM SET RIGHT

FRONT PANELS

T 1

Type 2 Split Window



A 0890-241 / 211 805 039 03/55-07/67
COMPLETE WINDOWSCREEN PANEL

C 0890-993 / 211 805 035C 07/59-07/63
FRONT PANEL

E 0890-960 07/59-07/63
INDICATOR MOUNTING PLATE (PAIR)


B 0890-992 / 211 805 035C 04/55-06/59
FRONT PANEL

D 0890-994 / 211 805 035C 08/63-07/67
FRONT PANEL

FRONT PANELS

T 1

Type 2 Split Window




A



B



C



D



E

A 0890-181 / 211 805 291 03/55-07/67
CROSSMEMBER UNDER DASHBOARD LHD

B 0890-975 / 211 805 333 03/50-07/67
INNER FRONTPANEL

C 0890-18 / 211 703 071B 03/50-07/67
INNER FRONT VALANCE WITH BRACKETS

D 0890-20 / 211 703 073A 03/50-07/67
OUTER FRONT PANEL WITH WELDING STRIP

E 0890-980 / 211 805 333 03/55-07/67
FRONT INNER FRAME ASSEMBLY LHD

FRONT PANELS

T 1


Type 2 Split Window



A



B



C D



E



F

G

A 0185-100 / 211 805 265A 03/50-12/62
HEADLIGHT BOWL

B 0185-200 / 211 805 265B 12/62-07/67
HEADLIGHT BOWL

C 0890-982 / 211 805 051M 03/55-06/61
DASHBOARD LHD

D 0890-983 / 214 805 051M 03/55-04/61
DASHBOARD RHD

E 0890-182 / 211 805 20 03/55-04/61
TRAY UNDER DASHBOARD


F 0890-184 / 211 415 605C 03/55-07/67
STEERING COLUMN BRACKET UNDER DASHBOARD

G 1370-555 / 211 415 637A + 211 415 631A 03/55-07/67
BUSHING WITH CLAMP UPPER STEERING COLUMN

BULKHEADS

T 1

Type 2 Split Window




A 0890-795 / 211 801 081C 08/55-07/62
BULKHEAD

B 0890-793 08/55-07/62
BULKHEAD TOP COVER FOR DELUXE MODEL

SIDE PANELS

T 1

Type 2 Split Window



A 0890-346 / 221 809 101C 03/55-07/62
SIDE PANEL LONG LEFT

B 0890-347 / 224 809 101C 03/55-07/62
SIDE PANEL SHORT LEFT

C 0890-356 / 224 809 102C 03/55-07/62
SIDE PANEL LONG RIGHT

D 0890-357 / 221 809 102C 03/55-07/62
SIDE PANEL SHORT RIGHT

E 0890-238 / 241 809 175A/G 03/50-07/67
SIDE WINDOW REPAIR PANEL LONG LEFT
4 WINDOWS

F 0890-236 / 244 809 175A/G 03/50-07/67
SIDE WINDOW REPAIR PANEL SHORT LEFT
2 WINDOWS



G 0890-239 / 244 809 176A/G 03/50-07/67
SIDE WINDOW REPAIR PANEL LONG RIGHT
4 WINDOWS

H 0890-237 / 241 809 176A/G 03/50-07/67
SIDE WINDOW REPAIR PANEL SHORT RIGHT
2 WINDOWS

SIDE PANELS

T 1

Type 2 Split Window



A 0890-359 / 221 809 102F 03/63-07/66
SIDE PANEL SHORT RIGHT

B 0890-348 / 221 809 101F 03/63-07/67
SIDE PANEL LONG LEFT


C 0890-358 / 224 809 102F 03/63-07/66
SIDE PANEL LONG RIGHT

D 0890-349 / 224 809 101F 03/63-07/67
SIDE PANEL SHORT LEFT

SIDE PANELS

T 1

Type 2 Split Window



A 0890-234 03/50-07/67
SIDE WINDOW INNER REPAIR PANEL
COMPLETE FOR 2 WINDOWS LEFT

C 0890-232 03/50-07/67
SIDE WINDOW INNER REPAIR PANEL
COMPLETE FOR 4 WINDOWS LEFT


B 0890-235 03/50-07/67
SIDE WINDOW INNER REPAIR PANEL
COMPLETE FOR 2 WINDOWS RIGHT

D 0890-233 03/50-07/67
SIDE WINDOW INNER REPAIR PANEL
COMPLETE FOR 4 WINDOWS RIGHT

SIDE PANELS

T 1

Type 2 Split Window



A 0890-674 / 211 809 342A 03/55-03/63
SIDE PANEL REINFORCEMENT VERTICAL
REAR LEFT

C 0890-673 / 211 809 311A 03/55-07/67
SIDE PANEL REINFORCEMENT VERTICAL

E 0890-672 03/55-07/67
SIDE PANEL REINFORCEMENT 31MM PROFILE

B 0890-675 / 211 809 342A 03/55-03/63
SIDE PANEL REINFORCEMENT VERTICAL
REAR RIGHT


D 0890-671 03/55-07/67
SIDE PANEL REINFORCEMENT 36MM PROFIL

F 0890-670 03/55-07/67
SIDE PANEL REINFORCEMENT 10MM PROFILE

REAR PANELS

T 1

Type 2 Split Window

**B****D****E****F****A.C.E****B.D.F**

A 0890-363 03/55-57
REAR CORNER COMPLETE LEFT

C 0890-364 / 211 813 355 57-59
REAR CORNER COMPLETE LEFT

E 0890-365 / 211 813 355 59-07/61
REAR CORNER COMPLETE LEFT

B 0890-373 / 211 813 356 03/55-57
REAR CORNER COMPLETE RIGHT



D 0890-374 / 211 813 356 57-59
REAR CORNER COMPLETE RIGHT

F 0890-375 / 211 813 356 59-07/61
REAR CORNER COMPLETE RIGHT

REAR PANELS

T 1

Type 2 Split Window



A 0890-366 / 211 813 355 08/61-12/63
REAR CORNER COMPLETE LEFT

B 0890-376 / 211 813 356 08/61-12/63
REAR CORNER COMPLETE RIGHT



C 0890-367 / 211 813 355G 01/64-07/67
REAR CORNER COMPLETE LEFT

D 0890-377 / 211 813 356G 01/64-07/67
REAR CORNER COMPLETE RIGHT

REAR PANELS

T 1

Type 2 Split Window



A 0890-393 / 211 813 225 03/55-07/63
ENGINE LID HINGE PANEL REINFORCEMENT

C 0890-39 / 211 813 227 03/55-07/63
ENGINE LID HINGE PANEL

E 0890-386 / 211 813 175B 08/58-07/65
REAR VALANCE COMPLETE

B 0890-394 / 211 813 217 08/63-07/66
ENGINE LID HINGE PANEL REINFORCEMENT

D 0890-39-1 / 211 813 227D 08/63-07/66
ENGINE LID HINGE PANEL

F 0890-387 / 211 813 175C 08/65-07/67
REAR VALANCE COMPLETE



REAR PANELS

T 1

Type 2 Split Window



D.E.F.G



A 0154-200 / 261 829 605 08/55-07/66
FUEL FLAP

C 0438-273 / 211 827 401A 08/71-07/92
ENGINE LID SUPPORT SPRING (25.50CM)

E 0157-430 / 211 827 025E 12/63-07/65
ENGINE LID

B 0157-25 / 261 829 551 03/55-07/75
HINGES ENGINE LID (PAIR)

D 0157-420 / 211 827 025B 05/58-12/63
ENGINE LID


F 0157-440 / 211 827 025E 08/65-07/66
ENGINE LID

G 0157-460 / 211 827 025F 08/67-07/71
ENGINE LID

PILLARS AND POSTS

T 1

Type 2 Split Window



A 0890-900 / 211 809 251D 03/55-12/63
B-POST COMPLETE LEFT, NON-CARGO DOOR

C 0890-901 / 211 809 251G 03/55-12/60
B-POST COMPLETE LEFT, CARGO DOOR



B 0890-903 / 211 809 252G 03/55-12/60
B-POST COMPLETE RIGHT, CARGO DOOR

D 0890-902 / 211 809 252D 03/55-12/63
B-POST COMPLETE RIGHT, NON-CARGO DOOR

PILLARS AND POSTS

T 1

Type 2 Split Window

**A****B****C****D**

A 0890-920 / 211 809 241A 03/55-12/60
C-POST COMPLETE LEFT, CARGO DOOR

C 0890-922 / 211 809 241E 12/60-07/67
C-POST COMPLETE LEFT, CARGO DOOR


B 0890-921 / 211 809 242A 03/55-12/60
C-POST COMPLETE RIGHT, CARGO DOOR

D 0890-923 / 211 809 242E 12/60-07/67
C-POST COMPLETE RIGHT, CARGO DOOR

PILLARS AND POSTS

T 1

Type 2 Split Window



A 0890-926 / 211 813 421A 03/55-07/63
D-POST COMPLETE LEFT

B 0890-927 / 211 813 422A 03/55-07/63
D-POST COMPLETE RIGHT

PILLARS AND POSTS

T 1

Type 2 Split Window

B.D**A.C****A****B****C****D**

BACK VIEW

BACK VIEW

BACK VIEW

BACK VIEW

A 0890-187 / 211 809 201B -07/63
A-POST COMPLETE LEFT

C 0890-187-1 / 211 809 201B 08/63-07/67
A-POST COMPLETE LEFT


B 0890-188 / 211 809 202B -07/63
A-POST COMPLETE RIGHT

D 0890-188-1 / 211 809 202B 08/63-07/67
A-POST COMPLETE RIGHT

PILLARS AND POSTS

T 1

Type 2 Split Window



A 0890-863 / 211 809 555 + 565 03/50-07/63
CONNECTING PROFILE A-B PILLAR LEFT
(INNER AND OUTER)

C 0890-865 / 211 809 555 + 565 07/63-07/67
CONNECTING PROFILE A-B PILLAR LEFT
(INNER AND OUTER)


B 0890-864 / 211 809 556 + 566 03/50-07/63
CONNECTING PROFILE A-B PILLAR RIGHT
(INNER AND OUTER)

D 0890-866 / 211 809 556 + 566 07/63-07/67
CONNECTING PROFILE A-B PILLAR RIGHT
(INNER AND OUTER)

ROOFS

T 1

Type 2 Split Window



A 0890-800 / 211 817 031A 03/55-07/67
ROOF


B 0890-801 / 225 817 031A 03/55-07/67
ROOF WITH SUNROOF CUT OUT

D 0890-820 / 211 817 031A/front 03/55-07/67
ROOF REPAIR PANEL FRONT BUS/PICK-UP

C 0890-802 / 241 817 031B 03/55-07/67
ROOF SAMBA/DELUXE

E 0890-830 / 211 817 031A/rear 03/50-07/67
ROOF REPAIR PANEL REAR

Type 2 Split Window



A 0890-803 / 241 817 121 + 125 03/50-07/67
SKYLIGHT INNER REINFORCEMENT LEFT


B 0890-804 / 241 817 122 + 126 03/50-07/67
SKYLIGHT INNER REINFORCEMENT RIGHT

C 0890-805 / 241 817 303 03/50-07/67
ROOF REINFORCEMENT FRONT

D 0890-806 / 211 817 323 03/55-07/67
ROOF REINFORCEMENT MIDDLE

E 0890-807 / 221 817 331 08/63-07/67
ROOF PANEL INNER BRACE REAR/ HATCH
DOOR HINGE SUPPORT

Type 2 Split Window



A 0890-890 / 211 817 511A 12/55-07/63
ROOF GUTTER FRONT WITH AIR INLET

B 0890-891 / 211 817 507A 08/63-07/67
ROOF GUTTER FRONT WITH AIR INLET

C 0890-867 / 211 817 517A 03/55-07/63
ROOF GUTTER FRONT LEFT

D 0890-868 / 211 817 518A 03/55-07/63
ROOF GUTTER FRONT RIGHT


E 0890-869 / 211 817 517A 08/63-07/67
ROOF GUTTER FRONT LEFT

F 0890-870 / 211 817 518A 08/63-07/67
ROOF GUTTER FRONT RIGHT

ROOFS

T 1


Type 2 Split Window



- A** 0890-871 / 211 817 537 03/50-07/63
ROOF GUTTER L+R
- C** 0890-872 03/55-07/63
ROOF GUTTER RIGHT (FOR CARGO DOORS)
- E** 0890-878 08/63-07/67
ROOF GUTTER RIGHT (FOR CARGO DOORS)
- G** 0890-876 08/63-07/67
ROOF GUTTER RIGHT

- B** 0890-873 03/55-07/63
ROOF GUTTER LEFT (FOR CARGO DOORS)
- D** 0890-877 08/63-07/67
ROOF GUTTER LEFT
- F** 0890-875 08/63-07/67
ROOF GUTTER LEFT (FOR CARGO DOORS)

Type 2 Split Window



A 0890-880 / 211 817 573 03/50-07/63
ROOF GUTTER REAR L/R

B 0890-881 / 211 817 567 08/63-07/67
ROOF GUTTER REAR LEFT

C 0890-882 / 211 817 568 08/63-07/67
ROOF GUTTER REAR RIGHT

D 0890-883 / 211 817 571A 03/50-07/63
ROOF GUTTER REAR

E 0890-884 / 211 817 571C 08/63-07/67
ROOF GUTTER REAR

BUMPERS

T 1

Type 2 Split Window




A 0019-200 / 211 707 135B 08/59-07/67
BUMPER BRACKET FRONT LEFT

B 0019-210 / 211 707 136B 08/59-07/67
BUMPER BRACKET FRONT RIGHT

C 0019-250 / 211 707 335A 08/59-07/67
BUMPER BRACKET REAR

Type 2 Split Window




A 0156-740 / 211 837 079 03/50-07/67
DOOR WINDOW FRAME LEFT

B 0157-750 / 211 837 080B 03/50-07/67
DOOR WINDOW FRAME RIGHT

SEATS

T 1

Type 2 Split Window



A 3400-200 03/55-07/62
FRONT SEAT FRAME BOTTOM AND BACK

C 3400-210 08/62-07/67
FRONT SEAT FRAME RIGHT 2/3 BOTTOM AND BACK

E 3400-320 08/63-07/67
MIDDLE SEAT FRAME BOTTOM AND BACK

B 3400-205 08/62-07/67
FRONT SEAT FRAME LEFT 1/3 BOTTOM AND BACK

D 3400-310 03/55-07/63
MIDDLE SEAT FRAME BOTTOM AND BACK

FRONT WHEEL ARCHES

T 1

Type 2 Split Window

B.D

A.C



A 0890-040 / 211 809 501 03/50-10/62
WHEEL ARCH FRONT LEFT

B 0890-050 / 211 809 502 03/50-10/62
WHEEL ARCH FRONT RIGHT


C 0890-105 / 211 809 501A 10/62-07/67
WHEEL ARCH FRONT LEFT

D 0890-115 / 211 809 502A 10/62-07/67
WHEEL ARCH FRONT RIGHT

CHASSIS

T 1

Type 2 Split Window



A 0890-58 / 211 801 361A 03/50-07/79
TOP HAT SECTION FRONT UNDER
RIBBED FLOOR

C 0890-58-2 / 211 801 371 03/50-07/59
TOP HAT SECTION REAR UNDER
RIBBED FLOOR

E 0890-59 / 211 801 381C 08/50-01/73
H-SECTION UNDER RIBBER FLOOR


G 0890-63 / 211 703 475C 03/55-07/67
CHASSIS OUTRIGGER CENTRE REAR

B 0890-58-3 / 211 801 363D 03/50-07/67
TOP HAT SECTION CENTER UNDER
RIBBED FLOOR

D 0890-58-1 / 211 801 371A 08/59-07/67
TOP HAT SECTION REAR UNDER
RIBBED FLOOR

F 0890-62 / 211 703 391B 03/50-07/67
CHASSIS OUTRIGGER CENTRE FRONT

Type 2 Split Window



A 0890-62L 03/50-12/59
CHASSIS OUTRIGGER REAR LEFT

C 0890-61L / 211 703 131 03/50-07/67
CHASSIS OUTRIGGER REAR LEFT AT
JACK SUPPORT

E 0890-60 / 211 703 125 03/50-07/67
CHASSIS OUTRIGGER FRONT

G 0890-52R / 211 703 622 03/50-07/67
JACKING POINT FRONT RIGHT


B 0890-62R 03/50-12/59
CHASSIS OUTRIGGER REAR RIGHT

D 0890-61R / 211 703 132 03/50-07/67
CHASSIS OUTRIGGER REAR RIGHT AT
JACK SUPPORT

F 0890-52L / 211 703 621 03/50-07/67
JACKING POINT FRONT LEFT

H 0890-53 / 211 703 631 03/50-07/67
JACKING POINT REAR

Type 2 Split Window



A 0890-305 / 211 809 581A/complete 03/50-07/67
SILL UNDER CARGO DOORS (COMPLETE)

B 0890-431 / 211 801 393 03/50-07/67
INNER SILL LEFT

C 0890-432 / 211 801 39 03/50-07/67
INNER SILL RIGHT




D 0890-642 / 211 703 305A 03/55-07/67
CHASSIS SECTION INNER PLATE FRONT LEFT

E 0890-652 / 211 703 312A 03/55-07/67
CHASSIS SECTION INNER PLATE FRONT RIGHT

CHASSIS

T 1

Type 2 Split Window



A 0890-641 / 211 703 021A 03/55-07/67
CHASSIS SECTION COMPLETE FRONT LEFT


B 0890-651 / 211 703 022A 03/55-07/67
CHASSIS SECTION COMPLETE FRONT RIGHT

C 0890-615 / 211 703 029C 03/55-07/67
MASTER CYLINDER CROSSMEMBER

CHASSIS


T 1

Type 2 Split Window



FRONT VIEW

BACK VIEW




A 0890-702
CHASSIS COMPLETE

03/55-07/59

PICK UP

T1/T2

Type 2 Split Window/Type 2 Bay Window



A 0168-115 / 261 829 051C 08/52-07/67
DROP GATE LEFT SINGLE CAB

C 0168-155 / 261 829 051C 08/52-07/79
DROP GATE REAR PICK-UP

E 0890-953 / 261 809 041C 08/62-07/66
SIDE PANEL SHORT LEFT SINGLE CAB

G 0890-955 / 261 809 042C 08/62-07/66
SIDE PANEL SHORT RIGHT SINGLE CAB

B 0168-125 / 261 829 052C 08/52-07/67
DROP GATE RIGHT SINGLE CAB

D 0890-949 / 261 809 041B 08/52-07/62
SIDE PANEL SHORT LEFT SINGLE CAB


F 0890-951 / 261 809 042B 08/52-07/62
SIDE PANEL SHORT RIGHT SINGLE CAB

H 0168-160 / 261 829 061D 08/52-07/65
TREASURE CHEST DOOR SINGLE CAB


PICK UP

T1/T2

Type 2 Split Window/Type 2 Bay Window



B.D.F.



A COMING SOON 58-62
REAR CORNER PICK-UP LH

C 0890-944 / 261 813 355C 08/63-07/66
REAR CORNER COMPLETE PICK-UP LEFT

E 0890-946 / 261 813 355E 08/66-07/67
REAR CORNER COMPLETE PICK-UP LEFT

B COMING SOON 58-62
REAR CORNER PICK-UP RH


D 0890-945 / 261 813 356C 08/63-07/66
REAR CORNER COMPLETE PICK-UP RIGHT

F 0890-947 / 261 813 356E 08/66-07/67
REAR CORNER COMPLETE PICK-UP RIGHT

PICK UP

T1/T2

Type 2 Split Window/Type 2 Bay Window



A 0168-001 / 261 829 453B 08/52-07/79
LATCH FRONT LEFT PICK-UP

B 0168-002 / 261 829 454B 08/52-07/79
LATCH FRONT RIGHT PICK-UP

C 0168-011 / 261 829 473B 08/52-07/79
LATCH REAR LEFT PICK-UP

D 0168-012 / 261 829 474B 08/52-07/79
LATCH REAR RIGHT PICK-UP

E 0168-003 / 261 829 447 08/52-07/79
LATCH CATCH FRONT LEFT/RIGHT PICK-UP

F 0168-013 / 261 829 445 08/52-07/79
LATCH CATCH REAR LEFT/RIGHT PICK-UP

G 0438-270 / 211 813 247 03/50-12/63
ENGINE LID SUPPORT PLATE

PICK UP

T1/T2

Type 2 Split Window/Type 2 Bay Window



A 0890-840 / 261 817 021A 03/55-07/67
ROOF SINGLE CAB

C 0890-781 / 261 805 421C 08/52-07/65
REAR WINDOW PANEL PICK-UP


B 0890-783 08/52-07/67
REAR WINDOW UPPER PANEL PICK-UP

D 0890-782 / 261 805 441B 08/52-07/67
REAR WINDOW PANEL CROSS BEAM PICK-UP

PICK UP

T1/T2

Type 2 Split Window/Type 2 Bay Window



A 0890-914 / 261 809 251D 03/55-12/63
B-POST COMPLETE LEFT, SINGLE CAB

B 0890-915 / 261 809 252D 03/55-12/63
B-POST COMPLETE RIGHT, SINGLE CAB

C 0890-78 / 261 805 431C/B/F 08/52-07/79
FRONT PANEL LOADING BED, PICK-UP

D 0890-797 / 261 801 081 08/52-07/67
BULKHEAD, SINGLE CAB

E 0890-772 / 261 801 485 03/55-07/65
DIVIDER PANEL ENGINE/FUELTANK, PICK-UP

F 0890-918 08/52-07/67
C-POST LEFT, SINGLE CAB

G 0890-919 08/52-07/67
C-POST RIGHT, SINGLE CAB


H 0890-924 / 261 813 417 -07/67
D-POST LEFT, PICK-UP

I 0890-925 / 261 813 418A -07/67
D-POST RIGHT, PICK-UP

PICK UP

T1/T2

Type 2 Split Window/Type 2 Bay Window




A 0890-763 / 261 801 465A 08/52-07/67
LOADINGBED FRONT (SINGLE CAB)

B 0890-764 / 261 801 475 08/52-07/67
LOADINGBED REAR (SINGLE/DOUBLE CAB)

PICK UP

T1/T2

Type 2 Split Window/Type 2 Bay Window




A 0890-746 / 261 801 401 08/52-07/67
FLOOR PLATE SINGLE CAB TREASURE
CHEST LEFT

B 0890-756 / 261 801 402 08/52-07/67
FLOOR PLATE SINGLE CAB TREASURE
CHEST RIGHT

PICK UP

T1/T2

Type 2 Split Window/Type 2 Bay Window



A 0890-889 / 261 817 517A 03/55-07/67
ROOF GUTTER LEFT SINGLE CAB

B 0890-888 / 261 817 518A 03/55-07/67
ROOF GUTTER RIGHT SINGLE CAB


C 0890-465 08/52-07/67
PLATFORM TRAY LEFT REAR PICK-UP

D 0890-475 08/52-07/67
BATTERY TRAY PICK-UP

PICK UP

T1/T2

Type 2 Split Window/Type 2 Bay Window





BACK VIEW

A 0890-597 08/52-07/71
SUPPORT FRAME UNDER LOADING BED PICK-UP

PICK UP

T1/T2

Type 2 Split Window/Type 2 Bay Window



A 0890-399 / 261 801 805 08/52-07/71
ENGINE LID HINGE PANEL PICK-UP

C 0890-398 / 261 801 870 08/52-07/71
SIDE GATE HINGE PANEL RIGHT SINGLE CAB

E 0890-316 / 261 809 585 08/52-07/71
SILL UNDER TREASURE CHEST DOOR
SINGLE CAB (COMPLETE)

B 0890-397 / 261 801 869 08/52-07/71
SIDE GATE HINGE PANEL LEFT SINGLE CAB

D 0890-58-5 / 261 801 803 08/52-07/79
TOP HAT SECTION UNDER RIBBED FLOOR
PICK-UP

F 0890-774 -07/67
DIVIDER PANELS ABOVE WHEEL ARCHES
ENGINE/FUEL TANK PICK-UP

Notes



BBT4VW.COM

BBT nv

Nijverheidsstraat 21
2960 Sint-Job-in-'t-Goor
Belgium

Tel +32 (0)3 633 22 22

Fax +32 (0)3 633 09 50

info@bbt4vw.com

BBT Wholesale: Monday - Thursday 8.00-17.00 Friday 8.00-15.00

Distribuito in Italia da:



CARS CANTONE ACCESSORI E RICAMBI S.R.L.

Via G. Razzaguta, 18

57128 Livorno – Italia

Tel 0586 260076

WhatsApp - 3284218144

P.I. IT01962660492